










AEOLUS | P2


1203
Case & Radiator Fan




▼ Package Contents

- A.  x3
- B.  x3
- C.  x12
- D.  x12
- E.  x1
- F.  x1
- G.  x1
- H.  x1
- I.  x1


▼ Turn off power



▼ Front




▼ Back




▼ Radiator


01




02




03



04




▼ Top




▼ Replace


01




02




03








▼ Connect



OR



▼ Instruction



PSU