

## Microphone P2X


User Manual

Thank you for choosing SYNCO product. Please read this manual carefully before use and follow all instructions mentioned herein.

## Caring For Your SYNCO Product

- Please keep the product in a dry, clean, dust-free environment.
- Keep corrosive chemicals, liquids and heat source away from the product to prevent mechanics damage.
- Use only a soft and dry cloth for cleaning the product.
- Malfunction may be caused by dropping, impact of external force.
- Do not attempt to disassemble the product. Doing so voids warranty.
- Please have the product checked or repaired by authorized technicians if any malfunctions happened.
- Failure to follow all the instructions may result in mechanics damage.
- Warranty does not apply to human errors.


## Package List



## Product Introduction


### 1. TX Transmitter

- ① Power Key
- ② Working Indicator
- ③ Built-in Microphone
- ④ Back Clip
- ⑤ Type-C Charging Port



### 2. RX Receiver

- ① Volume Button
- ② Type-C Port
- ③ Working Indicator
- ④ Connector



### 3. Indicator

\* Note: The indicator identification shown as follows.



#### ① Transmitter

Working Indicators (White Light) On:○ Flash:⚡	
Slow Flash * * * * *	Unpaired
Illuminate sequentially ◀◀◀◀◀◀◀◀◀◀	Paired, normal working
Single indicator keeps on ●	Noise cancellation on

#### ② Receiver

Working Indicators (White Light) On:○ Flash:⚡	
Slow Flash * * * * *	Unpaired
1~5 indicators on ●●●●●	Connected and working normally. The number of lights on indicates the current volume
Single indicator flashed slowly * * * * *	Mute on


## Operations

### 1. Turn On/Off

① Transmitter: Long press the power button of the transmitter for 3 seconds.

\*Note: The transmitter will shut down automatically if it is unpaired or disconnected for 5 minutes.


② Receiver: Insert the mobile phone device to switch on automatically, and the indicator flashes.



## 2. Charge

Transmitter:


Charge the transmitter via the Type-C charging port and charging cable.



Mobile Phone :

Insert your phone's charging cable into the Type-C port of the receiver when in use, and the charging current is adjusted according to the phone's battery max up to 800mA.

\*Note: The receiver does not need to be charged and can be used directly when plugged in the phone.



## 3. Pairing


The transmitter and receiver will automatically start pairing once power on.

\*Note: For P2XT/L, each receiver can only pair with two transmitters.

#### 4. Adjust the Volume

Press the receiver volume button to adjust the volume and the number of indicators shows the current volume level.


Double press the volume button to enable or disable mute and single indicator keeps on when mute is on.



#### 5. Noise Reduction

Press the power button of the transmitter to turn on the noise reduction, the single indicator keeps on.

\* Double press the power button of the transmitter to turn off/on the light effect.



## Specifications

### TX Transmitter

Wireless Transmission	Digital 2.4GHz
RF Frequency Band	2400-2483.5MHz
Frequency Response	20Hz-20KHz
Working Distance	492ft/150m(LOS area); 164ft/50m(NLOS area)
Sampling Rate	48KHz
Bit Depth	16Bit
Sensitivity	-36dB
SNR	> 75dB
Battery Type	Built-in Lithium Battery, 120mAh
Battery Charging Time	1.5H
Battery Life	5H
Dimensions	49x19x19 (mm)
Material	ABS
Weight	10g

### RX Receiver

Wireless Transmission	Digital 2.4GHz
RF Frequency Band	2400-2483.5MHz
Working Distance	492ft/150m(LOS area); 164ft/50m(NLOS area)
Sampling Rate	48KHz
Bit Depth	16Bit
Connector	Type-C or Lightning Output
Power Input	Type-C
Dimensions	49x30x9 (mm)
Material	ABS
Weight	5g

## Warranty

### Warranty Period

Thank you for purchasing SYNCO products.

1. Customers are entitled to free replacement or repair service in case of quality defect(s) found in the product under normal use within 30 days upon receipt of the product.
2. Original SYNCO products are entitled to 12-month limited warranty service. The warranty period begins on the date of purchase of brand new, unused products by the first end-user.

Within the warranty period, if product defect or failure is attributable to material deflection or technological problem, the defective product or defective part will be repaired or replaced without charge (service and materials fee).

### Warranty Exclusions and Limitations

Faults resulted from inappropriate use of a product without following its operation specification

1. Artificial damage, e.g. crash, squeeze, scratch, or soaking
2. Modifications to a product by its user or a third party without prior written consent of SYNCO, e.g. replacement of element or circuit, label alteration
3. The code on product is inconsistent with that of warranty certificate, or the code on the product or warranty certificate is altered or torn off
4. All consumable accessory attached to a product, like cable, wind muff, battery
5. Faults as a result of force majeure, such as fire, flood, lightning, etc.

### Warranty Claim Procedure

1. If failure or any problem occurs to your product after purchase, please contact a local agent for assistance, or you can always contact SYNCO's customer service through email at support@syncoaudio.com.
2. Please retain your sales receipt and warranty certificate as proof of purchase. If any of these documents is missing, only sales return or chargeable service will be provided.
3. If the SYNCO product is out of the warranty coverage, the service and the parts cost will be charged.

## WARRANTY CERTIFICATE

Product Model: \_\_\_\_\_

Date of Purchase: \_\_\_\_\_

Serial Number: \_\_\_\_\_

Malfunction Description : \_\_\_\_\_

Buyer Name: \_\_\_\_\_

Buyer Telephone : \_\_\_\_\_

Buyer Mail : \_\_\_\_\_

Buyer Address : \_\_\_\_\_

Dealer : \_\_\_\_\_

Dealer Telephone : \_\_\_\_\_

Delivery Date : \_\_\_\_\_

Cause of Malfunction : \_\_\_\_\_

Maintenance Personnel : \_\_\_\_\_

Malfunction Processing : \_\_\_\_\_

\*Please register your warranty. Meanwhile, you are welcomed to contact us via Email: support@syncoaudio.com

### Guangzhou Zhiying Technology Co., Ltd

Room 2401, 24 / F, South Tower, Lisheng Plaza, No. 68 Huadi Avenue, Liwan District, Guangzhou, China, 510000

support@syncoaudio.com

www.syncoaudio.com